

Safety Precautions

Warning: For your safety:



Arc welding dangerous

- In order to avoid unnecessary casualties, please protect your and other people's safety, children should be away from the welding site, the operator must wear protective clothing and glasses!



Electric shock will hurt you

- Before using the device, the power supply and water containers must be reliably grounded!
- In the process of welding, the temperature of electrode and workpiece is very high, please do not let your skin and damp cloth touch these hot parts, in order to prevent your hands from being injured, please put on dry gloves for construction!
- Use dry insulating materials so that you and your workpieces can be isolated, and the insulating material should have sufficient surface!
- In the process of automatic welding, the temperature of the electrodes, welding head, nozzle and torch is respectively quite high!
- Ensure that the working cable is well connected to the welded parts, and it should be close to welding joints of the workpiece!
- The workpiece and the welded metal need to be grounded well.
- In the safe operation mode, please check whether the electrode, ground clamp, welding cable and welding machine are intact, replace the damaged components!
- The electrode can not be cooled by water!
- Do not touch the conductive parts connected to the two welding electrodes at the same time!



Arc rays may cause injury on the human body

- When it comes to welding, please wear the safety goggles to avoid hurt caused by sparks and arc rays!
- Please wear protective clothing made of flame-retardant materials to ensure that your skin is kept away from arc radiation damage!



Smoke is harmful to health!

- The smoke dust produced during welding is harmful to health, so try to avoid inhaling the smoke dust!
- The shielding gas used for welding may be inhaled at the expense of people's health, so the welding site must be well-ventilated in order to ensure that the inhaled air is clean!



Welding sparks may cause fire

- Keep the combustible away from the welding spot, if the combustible cannot be moved, then use the flame-retardant materials to cover them!
- Remember that welding sparks and hot metal are very easy to splash, a fire extinguisher must be prepared!
- If you use compressed air in the welding process. Please take necessary protective measures!
- When welding is stopped, the electrode should not touch the workpiece, so as to avoid overheating of the workpiece!



Damage of gas cylinder will cause the explosion

- Use a good compression cylinder, and the intact control valve must be installed, all of the air tubes, filters should be intact and proper!
- The cylinders must be installed uprightly, and the cylinder needs to be fixed!
- Prepare enough space to install gas cylinders so as to avoid collision with each other, resulting in physical damage!
- The gas cylinder must be away from the welding site or other fire sources!
- Prohibit the use of electrodes, electrode clip, or other alive parts to contact with gas cylinders!
- When you open the cylinder valve, your head and face must not face the exit of valves!
- Do not remove valve's protection cap and the handle, unless the gas cylinders are in use or ready to be used!



The noise exceeded 70 dB will cause permanent hearing damage

- Please take the appropriate earmuffs or earplugs!
- Ensure that the noise will not impact other personnel passing the working area!



Electromagnetic interference may affect the normal use of welding equipment

- The welding equipment must have a regular maintenance!
- The wire should be as short as possible, and should be close to or touch the ground!

-
- Protection of other conductors and equipments can reduce the effects of radiation!



When welding equipment running, it could produce electromagnetic interference with surrounding electronics

- The welding equipment at work must be kept away from the electronic products that may be interfered!
- If it is used near the computers and electronic products susceptible to interference, associated electronic equipments should be turned off!



Danger may be caused by violating operational procedures

- Be sure to read instructions carefully before using the equipment!
- Prohibit the use of the equipment by layman!



Our instruction makes a description of safe use of the equipment for you, which can reduce the occurrence of the accident, so please carefully read the instructions before using the device.













Technical Parameter

| | |
|--|--|
| Power Source Model | PC508 |
| Welding Power Supply | 420A |
| Open Circuit Voltage | 98V |
| Input Voltage | 380±10% 50 HZ |
| Max Power | 23.1KVA |
| Torch Cooling | Water cooling |
| Display | 5-inch color LCD |
| Control Function | High-resolution DC /pulsed current control |
| | Current gradient control |
| | AVC control |
| | OSC control |
| | Constant/ pulsed speed welding traveling control, achieve sector-able traveling speed control function |
| | Constant / pulsed speed wire feed control, achieve sector-able wire feed speed control function |
| | Shielding gas , cooling water pump automatic control |
| USB Interface | It can be used to download and store user program (optional) |
| Number of program stored | 100 |
| Real-time data display in the process of welding | Welding current display Welding process show Welding arc voltage display |
| Number of sector | 32 |
| Automatic diagnosis system | Error display |
| Dimension | 630 * 415 * 645 (mm) |
| Weight | 64 KG |

I Device Profile

1. Whole Structure

1.1 Front structure of device

1. Dust cover, prevent dust from polluting the equipment
2. LCD display, operating interface
3. Program lock, avoid illegal changes
4. Handle, for moving the devices
5. Shockproof caster wheel
6.  function key --- editing keyboard for the main menu, edit and modify the program
7.  function key --- weld / simulate option for operate
8.  auxiliary key --- help and tips
9.  function keys --- up-select and down-select user programs, as well as modify user programs
10.  Select letters leftward
11.  Select letters rightward
12.  Select upward, move a line once
13.  Select downward, move a line once
14.  Selection of program number, increase or decrease value
15.  Selection of program number, increase or decrease value
16.  Move the cursor, scroll one page upward once
PgUp
17.  Move the cursor, scroll one page downward once
PgDn
18. Remote control interface
19. AVC/OSC control interface
20. Welding head movement interface
21. Wire feed interface
22. Shielding gas outlet port
23. ARC voltage Feedback interface
24. Cathode outlet
25. Anode outlet
26. Cooling water outlet

27. Cool water inlet

28. Water tank



2 Back structure of device

29. Hot-wire power supply interface (option)


















30. Shielding gas inlet

31. Power switch

32. Power inlet



3 Structure and Function of Remote Control

| Symbol | Functional Description |
|---|--|
|  | Program reset |
|  | Start welding |
|  | Displayer, display the current program number |
|  | Program selection button, select the desired program (press once, ± according to the order call for the next program) |
|  | Stop button to stop welding (press once to stop welding, welding head back to start position; press twice, and completely stopped) |
|  | Downslope button (press once, weld current slope down to 0, then welding head back to start position) |
|  | In the case of idlesse , welding head rotate forward, used to adjust the position |
|  | In the case of idlesse, welding head rotate reverse, used to adjust the position |
|  | Indicator LED |
|  | Manual wire feeding function key |
|  | Wire feeder Reverse manual y in the case of idlesse |
|  | Tungsten needle enhancing |
|  | Tungsten needle dropping |
|  | Tungsten needle swing inward |
|  | Tungsten needle swing outward |
|  | Test gas / current increase, in the process of welding, press the button once, the current increases ΔI by parameter settings , in the case of idlesse press to test Shielding gas Flowing |
|  | Test water / current decrease, in the process of welding, press the button once, the current decreases ΔI by parameter settings |




II System Parameter

| Content | Label | Content | Label |
|--------------------------------------|-------|--------------------------------------|-------|
| DIA—Diameter of tube | DIA | HCd —Welding Head code | RN |
| IMd —Current mode | K21 | RMd — Rotation mode | K31 |
| WF —Wire feed or not | K41 | WCd —Wire feeder code | SN |
| AVC —AVC control | K51 | ACd —AVC Module code | HN |
| OSC —OSC or not | K61 | OCd —OSC Module code | WN |
| SEC —The number of sector | B | RDg — Rotation degree | N20 |
| GPre —Gas pre- shield time | T10 | GLag — Gas lag-shield time | T11 |
| IPre —Pre-melting current | I20 | TPre — Pre-melting time | T20 |
| TUp —Up-slope time | T21 | TW — Initial electrode height or not | K53 |
| TDn —Down-slope time | T25 | IED — Arc shut current | I25 |
| Page 2 | | | |
| TH — electrode initial height | H50 | TLH — Torch Lifting height | H51 |
| RD _i — Rotation direction | K32 | HH — Head homing or not | K33 |
| WMd — Wire feed mode | K42 | WSDg — Wire feed start degree | N40 |
| WEDg —Wire feed shut degree | N41 | WBT — Wire back extraction time | T41 |
| AT —AVC sampling time | T50 | OSDg — OSC start degree | N60 |
| AD _i —AVC direction | K55 | | |
| Page 3 | | | |
| DI — Current increment | DI | DV — Rotation speed increment | DV |
| DW — OSC offset | DW | DH —Arc-length increment | DH |
| Page 4 | | | |
| SP — Sector point | Nn | IPT — Current peak value time | T22 |
| IBT — Current base value time | T23 | PI — Peak current value | I22 |
| BI — Base current value | I23 | PRS — Peak Rotation speed | V32 |
| BRS — Base Rotation speed | V33 | PWS — Peak wire feed speed | V42 |
| BWS — Base wire feed speed | V43 | AU— AVC tracking voltage | V50 |
| OW — OSC width | W60 | OS — OSC speed | V60 |
| OES — OSC Edge stay | T60 | ES — Edge synchronization | K62 |
| SMD — Sector exchange mode | K22 | | |


***Note: parameters vary with the type of each device model;**

After the fourth page, each section for one page;

OSC offset: When using the 85E welding header, OSC offset should be greater than 0, otherwise the offset will not be achieve.



〔Pulse current, pulse traveling, pulse wire feed synchronization I〕



〔Wire feeding, traveling and pulse-current synchronization II〕

III Operation of Equipment


3.1 Set parameters through the control panel

Switch on the power switch, devices enter into idle mode, at this time the host operating interface sub-screen displays the following contents line by line, the specific content color is related to the parameters, in the case of no wire feeding, the item of base speed wire feeding, etc. is displayed as dark, indicating that this item does not active, parameter value shown in starting is the value of the last time been used.

| Content | Label | Content | Label |
|--------------------------------------|-------|--------------------------------------|-------|
| DIA—Diameter of tube | DIA | HCd —Welding Head code | RN |
| IMd —Current mode | K21 | RMd — Rotation mode | K31 |
| WF —Wire feed or not | K41 | WCd —Wire feeder code | SN |
| AVC —AVC control | K51 | ACd —AVC Module code | HN |
| OSC —OSC or not | K61 | OCd —OSC Module code | WN |
| SEC —The number of sector | B | RDg — Rotation degree | N20 |
| GPre —Gas pre- shield time | T10 | GLag — Gas lag-shield time | T11 |
| IPre —Pre-melting current | I20 | TPre — Pre-melting time | T20 |
| TUp —Up-slope time | T21 | TW — Initial electrode height or not | K53 |
| TDn —Down-slope time | T25 | IEd — Arc shut current | I25 |
| Page 2 | | | |
| TH — electrode initial height | H50 | TLH — Torch Lifting height | H51 |
| RD _i — Rotation direction | K32 | HH — Head homing or not | K33 |
| WMd — Wire feed mode | K42 | WSDg — Wire feed start degree | N40 |
| WEDg —Wire feed shut degree | N41 | WBT — Wire back extraction time | T41 |
| AT —AVC sampling time | T50 | OSDg — OSC start degree | N60 |
| AD _i —AVC direction | K55 | | |
| Page 3 | | | |
| DI — Current increment | DI | DV — Rotation speed increment | DV |
| DW — OSC offset | DW | DH —Arc-length increment | DH |
| Page 4 | | | |
| SP — Sector point | Nn | IPT — Current peak value time | T22 |
| IBT — Current base value time | T23 | PI — Peak current value | I22 |
| BI — Base current value | I23 | PRS — Peak Rotation speed | V32 |
| BRS — Base Rotation speed | V33 | PWS — Peak wire feed speed | V42 |
| BWS — Base wire feed speed | V43 | AU— AVC tracking voltage | V50 |
| OW — OSC width | W60 | OS — OSC speed | V60 |
| OES — OSC Edge stay | T60 | ES — Edge synchronization | K62 |
| SMD — Sector exchange mode | K22 | | |

3.2 Editing Parameters F1

In idle mode, unlock programs lock, press the  to get operating tips, as shown in figure,

Press the  key to enter editing state, at this time, the cursor is at the position of program number |.



F1 Modify the parameters
F2 Select simulate or weld mode
F3-F1 Selection of user program
F3-F2 Operation with memory card
F3-F4 Welding parameter

| Program number 00 | TEST | | Weld | | |
|----------------------------|--------|--------|--------------------------------------|-----|--------|
| DIA—Diameter of tube | DIA | 38 | HCd —Welding Head code | RN | S112 |
| IMd —Current mode | K21 | Pulsed | RMd — Rotation mode | K31 | Pulsed |
| WF —Wire feed or not | K41 | No | WCd —Wire feeder code | SN | 97 |
| AVC —AVC control | K51 | Yes | ACd —AVC Module code | HN | 21 |
| OSC —OSC or not | K61 | Yes | OCd —OSC Module code | WN | 21 |
| SEC —The number of sector | B | 2 | RDg — Rotation degree | N20 | 360 |
| GPre —Gas pre- shield time | T10 | 3 | GLag — Gas lag-shield time | T11 | 3.2 |
| IPre —Pre-melting current | I20 | 32 | TPre — Pre-melting time | T20 | 1.0 |
| TUp —Up-slope time | T21 | 0.1 | TW — Initial electrode height or not | K55 | Yes |
| TDn —Down-slope time | T25 | 4.2 | IEd — Arc shut current | I25 | 13 |
| F4 operation tips | 13: 10 | | A-hand | | |

Rule of program name

- Rule of program name: A total of 100 programs for 00-99, each program's name is represented with a character.
- When you need a new program, this device provide two solution:
 - I Modify a existing program by the editing function
 - II Load new welding parameters by computer downloading (option)

3.2.1 Editing program number (if need to select No. 5 program , for example)

















Press the   button to select the user program number 05 you need to edit;

If you need to modify the edited name of the program, re-input it according to the above method.




3.2.2 Editing welding parameters

In the editing mode, after (editing) modification of program name, edit the parameters according to the following



| | | | | | |
|----------------------------|-----|--------|--------------------------------------|-----|--------|
| DIA—Diameter of tube | DIA | 38 | HCd —Welding Head code | RN | S112 |
| IMd —Current mode | K21 | Pulsed | RMd — Rotation mode | K31 | Pulsed |
| WF —Wire feed or not | K41 | No | WCd —Wire feeder code | SN | 97 |
| AVC —AVC control | K51 | Yes | ACd —AVC Module code | HN | 21 |
| OSC —OSC or not | K61 | Yes | OCd —OSC Module code | WN | 21 |
| SEC —The number of sector | B | 2 | RDg — Rotation degree | N20 | 360 |
| GPre —Gas pre- shield time | T10 | 3 | GLag — Gas lag-shield time | T11 | 3.2 |
| IPre —Pre-melting current | I20 | 32 | TPre — Pre-melting time | T20 | 1.0 |
| TUp —Up-slope time | T21 | 0.1 | TW — Initial electrode height or not | K55 | Yes |
| TDn —Down-slope time | T25 | 4.2 | IEd — Arc shut current | I25 | 13 |

- 1、 Press  key to move the cursor to the next parameter diameter DIA
- 2、 Press   to select the parameter of diameter of desired pipe to be welded;
- 3、 Press  to move the cursor to the next item header code RN;
- 4、 Press   to select header code item, and press   to select the figure code;
- 5、 Press  to move to current-mode K2 1 pulsed;
- 6、 Press   to switch between pulsed / DC;
- 7、 Press  key to move the cursor to the traveling mode K31 constant speed;
- 8、 Press   to switch between pulsed / constant speed;
- 9、 When the cursor is at the position of a parameter, press   key to change the value of this parameter, determine the parameter value you want. If the parameter value cannot be changed, it indicates that the value of this parameter has reached the maximum or minimum.
- 10、 In the case of sub-section, press F1 key to jump the page, take a direct jump to a page.


Attention!

- ※ In the editing mode, press  , scroll a line every time, for   key, scroll a screen every time.
- ※ In the editing of parameters, the cursor can not reach some parameters , this means it is mainly subject to the priority of parameter setting, for example ,when current mode is DC, the traveling mode and wire



feeding mode cannot be an option, the cursor directly skips to the next one!




- ※ In the editing of parameters, usually the dark parameters cannot be changed.
- ※ Parameters in the fourth page is parameters effect that sector been marked, set the parameter of each section and its value separately, when the screen is at the end of certain paragraph, press  key, then the parameter of this paragraph is same as the previous one.
- ※ Press  button, and the picture will be presented on screen when set the parameters and values of all pages

F1 To other sector
F2 Same as previous one
F3
F4 Exit

Press  button, and the picture will be presented on screen

F2 Save
F3 Don't Save

Press  or  as necessary to save or not save the set parameters and exit.


- ※ Press  twice consecutively to save the program, pressing  twice consecutively will not save it, return to idle mode
- ※ Press  key to see list of empty program in order to store the edited program

3. 3 simulate or weld select F2

In order to determine whether the parameters of program is proper before welding and accuracy of positioning, operator can run simulate process, when set the **simulate** mode, start welding, the welder simulates actual state of welding process without ARC in order to make the appropriate adjustments.



In idle mode, press , panel shows as below.

| Program number 00 | | | Simulate | | |
|----------------------------|-----|--------|--------------------------------------|-----|--------|
| DIA—Diameter of tube | DIA | 38 | HCd —Welding Head code | RN | S112 |
| IMd —Current mode | K21 | Pulsed | RMd — Rotation mode | K31 | Pulsed |
| WF —Wire feed or not | K41 | No | WCd —Wire feeder code | SN | 97 |
| AVC —AVC control | K51 | Yes | ACd —AVC Module code | HN | 21 |
| OSC —OSC or not | K61 | Yes | OCd —OSC Module code | WN | 21 |
| SEC —The number of sector | B | 2 | RDg — Rotation degree | N20 | 360 |
| GPre —Gas pre- shield time | T10 | 3 | GLag — Gas lag-shield time | T11 | 3.2 |
| IPre —Pre-melting current | I20 | 32 | TPre — Pre-melting time | T20 | 1.0 |
| TUp —Up-slope time | T21 | 0.1 | TW — Initial electrode height or not | K55 | Yes |
| TDn —Down-slope time | T25 | 4.2 | IEd — Arc shut current | I25 | 13 |
| F4 operation tips | | 13: 10 | A-hand | | |











In simulate ,press  again to present the weld state.

| Program number 00 | | | Weld | | |
|----------------------------|-----|--------|--------------------------------------|-----|--------|
| DIA—Diameter of tube | DIA | 38 | HCd —Welding Head code | RN | S112 |
| IMd —Current mode | K21 | Pulsed | RMd — Rotation mode | K31 | Pulsed |
| WF —Wire feed or not | K41 | No | WCd —Wire feeder code | SN | 97 |
| AVC —AVC control | K51 | Yes | ACd —AVC Module code | HN | 21 |
| OSC —OSC or not | K61 | Yes | OCd —OSC Module code | WN | 21 |
| SEC —The number of sector | B | 2 | RDg — Rotation degree | N20 | 360 |
| GPre —Gas pre- shield time | T10 | 3 | GLag — Gas lag-shield time | T11 | 3.2 |
| IPre —Pre-melting current | I20 | 32 | TPre — Pre-melting time | T20 | 1.0 |
| TUp —Up-slope time | T21 | 0.1 | TW — Initial electrode height or not | K55 | Yes |
| TDn —Down-slope time | T25 | 4.2 | IEd — Arc shut current | I25 | 13 |
| F4 operation tips | | 13: 10 | A-hand | | |

3.4 Selection of program



In idle mode, press   key at same time to enter the following interface

| Serial No. | Program Name | Diameter | Occupied Main Memory |
|------------|--------------|----------|----------------------|
| 0 | PRG55 | Φ 52 | 0.4 % |
| 1 | PRG99 | Φ 10 | 0.4 % |
| 50 | | Φ 61 | 0.4 % |
| 60 | | Φ 52 | 0.4 % |


Press   to select the program, press  to identify and exit, press  to deselect. In addition, you can use   on the panel to increase and decrease the programs one by one and press  for identification. You can also use the   on the remote control one by one to change program, and press  for identification.

Note: If cancel the option, the system will be defaulted to return to the largest program number 99.




3.5 The embedded memory operation


In idle mode, press   into the embedded memory operation, the system enters the following interface

F1 Delete
F2 USB flash drive
F3
F4 Exit

3.5.1 Press  to delete the stored program, then the tips display on the screen as below

F1 delete all
F2 delete selected
F3 Exit

Then press   key to select the program you want to delete, and then press  to confirm. As shown below



Choose to delete all or part of programs as you need.

3.5.2 Press **F2** for the U disk operation, then the screen displays **UDisk test**, wait a moment, the system enter the following interface

| Serial No. | Program Name | UDiskU |
|------------|--------------|--------|
| 50 | | + |
| 60 | | +.. |
| | | +WEL0 |

F1 Content change F2 Selection F3 Subdirectory building F4 Exit

Note: “+.”and “+ ..” mean that WEL0 is the subdirectory built by device in default under the root directory.

According to the tips at the bottom of the screen: Press F1 to enter subdirectory of disk U. Press **←** **→** to switch between the embedded memory and disk U.



F3 indicates that build a new subdirectory under the directory of disk U.

Namely press **F1** to switch the cursor to the disk U directory, press **F3**, a + WEL1 subdirectory is added in disk U. You can build multiple subdirectories successively.




F2 option key, it is used to copy programs between the system embedded memory and the disk U.

To copy the system program to disk U, press **F1** to enter directory of disk U, select a subdirectory you want store, such as WEL0, press **F1**, enter WEL0 interface, as shown in figure

| Serial No. | Program Name | Disk U |
|------------|--------------|--------|
| 50 | | -. |
| 60 | | -.. |

Switch the cursor to the system program column, select the program number you want to copy, for example: program 50 , press  select, then the program number 50 becomes red, press  to copy it to disk U. As shown in figure

| Serial No. | Program Name | Disk U |
|------------|--------------|--------|
| 50 | | -. |
| 60 | | -.. |
| | | -PRG50 |



If you want to copy the program to the system from the disk U (for example, PRG55 in WEL1 subdirectory copied to the system), firstly press  to enter WEL1 directory of disk U, press  to select PRG55, at this time PRG55 turns red, press  to copy it to the system memory. As shown in Figure

| Serial No. | Program Name | Disk U |
|------------|--------------|--------|
| 0 | PRG55 | -. |
| 50 | | -.. |
| 60 | | -PRG55 |

Press  to exit Disk U operation .

Note: Program in Disk U can not be deleted in the machine.

3.6 Welding parameters

In idle mode, press the key _ at same time, you can see the actual value of each parameter after the end of the machine welding.


Attention!

When input the reference program, the new program will cover the existing program, we remind you of choosing the vacant or unfamiliar position to input the program number in order to avoid loss of data!

IV Parameter Setting

4.1 Gas Flow control

You may set the time of pre-shield gas and lag-shield gas as required (as shown in Item 1 in the figure)



4.1.1 Pre-shield time T10.

Set parameters of shielding gas through the control panel, see **3.2.2 editing of parameter of 3.2 Set parameters of shielding gas through the control panel.**

4.1.2 Lag-shield time T11



Set parameters of shielding gas through the control panel, see **3.2.2 editing of parameter of 3.2 Set parameters through the control panel.**

4. 2 Current control

Current may adopts pulse / DC control mode, you can set the following parameters as required (as shown in Item 2 in the figure), and you can set corresponding current parameters in each sector according to demand (see **4.7 interval setting** for mode of sector setting,).

| | |
|------------------------------|--------------------------|
| Current mode K21 | up-slope time T21 |
| Pre-melting current I20 | Pre-melting time T20 |
| pulsed current I22 | pulsed time T22 |
| Base current I23 | Base time T23 |
| Arc shut current I25 | down-slope time T25 |
| Current increment ΔI | Intersegment current K22 |

Set parameters of current through the control panel, see **3.2.2 editing of parameter of 3.2 Set parameters through the control panel.**




Remark: changing the current by remote control in welding process is under restrictions by parameter setting, if the increments of 0 in parameter setting, then the current increment cannot be changed, otherwise, every time press the button, the current increment is ΔI .

In the sector, the current during sector exchange may choose linear decreasing, which is very useful to weld the workpiece with small diameter.

4. 3 Welding torch travel control

Torch rotation direction can be set as Forward / reversal; whether the header homing automatically and other parameters.

traveling direction K33 traveling mode K31
Header homing K34



To be con

Set parameters of traveling control through the control panel, see **3.2.2 editing of parameter of 3.2 Set parameters through the control panel.**

Remark: Using of header with the AVC tracking, after a welding process, for header returns to home, it can automatically enhance the height of tungsten electrode to avoid that may contact with the welding pieces, achieving the purpose of tungsten electrode protection.



4. 4 Arc voltage control

The system has the AVC arc voltage automatic control function, and according to the technical characteristics, set arc voltage for each sector. In the process of welding, arc voltage automatic control system can take a automatic adjustment of arc length according to feedback, ensuring the consistency of arc length in the whole process of welding in order to ensure the consistency welding forming.

The following parameters can be selected according to technical requirements:

Enable or disable AVC control K51 AVC module code HN
 Automatic height K53 Electrode initial height H50
 Sampling time T50 Arc voltage U5

Set parameters through the control panel, see **3.2.2 editing of parameter** of **3.2 Set parameters through the control panel**.

| | |
|---|--|
|  | Enhance arc length during weld process |
|  | Reduce arc length during weld process |

Remark 1:


In the regulation of tungsten electrode height, try not to use the AVC system, if you use carelessly, motor is stuck, so that the automatic tracking system will fail. To try to keep that the AVC slide is in the middle of the slider (in the process of welding, ensure enough adjusting space of the AVC slider to keep AVC control function-able)

Remark 2:

This system provides the function of automatic initial of tungsten electrode height, the corresponding parameter is Initial electrode height K53 and electrode initial height H50, the tungsten electrode is only required to aim at the welding line before welding, tungsten electrode height will initial automatically, which reducing operator's burden.

4.5 OSC control


1. OSC start degree: start OSC after certain degree of the main traveling.
2. Edge synchronization: whether the pulsed current is synchronous at the OSC edge .
3. Edges stay: edge duration inOSC.
4. OSC width: 0.2mm-25.5mm.
5. OSC speed: 20mm/min-1500mm/min (vary with the lower limit of different OSC mechanisms)
6. Edge stay: 0ms-2500ms



4. 6 Wire feed control





The wire feed of this machine has pulse function, the wire feed and current pulse are in the synchronization, you can select the following parameters on demand (as shown in Item 4 of the Figure).

- | | |
|---------------------------|-------------------------------|
| Wire feed or not K41 | Wire feeder module code SN |
| Wire feed mode K42 | Wire feed start degree N40 |
| Pulse wire feed speed V42 | Base wire feed speed V43 |
| Wire feed shut degree N41 | Wire back extraction time T41 |




(1) Set parameters through the control panel, see **3.2.1 editing of parameter** of **3.2 Set parameters through the control panel**.

(2) Manual wire feed can be realized through the remote control in the process of welding (state of no wire feed in the program):

| | |
|---|------------------------------------|
|  | Indicator |
|  | Manual wire feeding function key |
|  | Used to adjust the wire's position |
|  | Used to adjust the wire's position |

4. 7 Traveling control

The machine has a powerful function of control of weld traveling, you can set the following parameters (as shown in Item 3 of the Figure):



Traveling mode K31
Traveling degree N20
Pulse traveling speed v32
Base traveling speed v33

Set parameters through the control panel, see **3.2.2 editing of parameter of 3.2 Set parameters through the control panel.**

Remark:

The current supply can be set to the synchronization of traveling and current pulse at pulse current, also can be set to the special speed in order to increase penetration, improve welding quality, and meet all the strict requirements!

4. 8 Sector setting

PC508 power supply has a sector-able parameters control function, a welding process can be divided into 32 sectors in order to significantly improve the welding quality.

Set parameters through the control panel, see **3.2.2 editing of parameter** of **3.2 Set parameters through the control panel**.

When you set multiple sectors, we need to carry out synchronization setting for the corresponding parameters of each sector!


For example: a particular welding parameter need to be divided into five sections for welding, you need to set the corresponding parameters according to the following steps

Sub-sector number 2

| | sector 1 | sector 2 | sector 3 | sector 4 | sector 5 | sector 6 | sector 7 |
|----------------------------------|----------|----------|----------|----------|----------|----------|----------|
| Sector start point N2 (0) | 15 | 90 | 180 | 270 | 360 | | |
| Pulse current value I22 (A) | 170 | 170 | 168 | 166 | 165 | | |
| Base current I23 value (A) | 60 | 60 | 60 | 60 | 60 | | |
| Current pulse value time T22(ms) | 100 | 100 | 100 | 100 | 100 | | |
| Current base value time T23(ms) | 200 | 200 | 200 | 200 | 200 | | |
| Pulse Rotation speed v32(mm/m) | 100 | 100 | 100 | 100 | 100 | | |
| Base Rotation speed v33(mm/m) | 100 | 100 | 100 | 100 | 100 | | |
| Pulse wire feed speed v42(mm/m) | 1200 | 1200 | 1200 | 1200 | 1200 | | |
| Base wire feed speed v43(mm/m) | | | | | | | |
| Arc voltage U5(U) | 10.0 | 10.0 | 10.0 | 10.0 | 10.0 | | |

Therefore, when input the parameter, you must pay attention to setting number of the sector, set the appropriate parameters in strict accordance with pre-set sector synchronization, if several sector marks have the same start degree, then the program will run the parameters set by degree of the last sector mark.



The relationship of the sector, sector mark, and number of sector





V. Notes

- Parameters can be divided into welding parameters and debugging parameters according to the functions. All of the incremental setting parameters are debugging parameter!
- In order to effectively reflect the reproducibility of welding, all the incremental setting parameters are proposed to be used in debugging!
- In the state of editing, the remote control keys (except for emergency stop button) and the head button are automatically locked!

VI Parameter Quick Search

While using device, in order to quickly find the required program, the equipment provides fast query function, in idle mode, press the key - at same time, show as follows:

| Program Name | Program Name | Diameter | Occupied main memory |
|--------------|--------------|----------|----------------------|
| 0 | PR55 | Ø52 | 0.4 % |
| 1 | PRG90 | Ø25 | 0.4 % |
| 50 | | Ø38 | 0.4 % |
| 60 | | Ø57 | 0.4 % |
| . | | | |
| . | | | |

select the desired program, press  for selection of program, press  to exit.



VII How to Set Appropriate Welding Parameters

In the process of debugging a complex parameter, it is often necessary to debug the parameters for many times in order to determine an appropriate welding parameters, you can use the following methods:

- Prepare a experience value parameter by experience
Only one section is the best for the parameters, and set the corresponding current increment.

After making preparation according to steps of “**preparation before welding by eight**”, “**start welding by nine**”, and begin to welding, observe the conditions of furnace

of hearth during welding. Adjust the current increment in order to achieve the desired welding effect.

- After the trial welding, press   key to show the relationship between the angle and current changes in the process of welding (as shown in Figure)
- According to the above relationship between the angle and current changes, optimize welding parameters in section, until you find the ideal welding parameters.
- Welding parameters after storage adjustment are used for later calls.

| | | |
|-----|---------|------|
| 50 | 120A | 10.1 |
| 80 | 118A | 10.1 |
| 120 | 115A | 10.1 |
| | ◦ ◦ ◦ | |
| | ◦ ◦ ◦ ◦ | |
| 360 | 97A | 10.1 |

VIII Weld Preparation

8. 1 Start-up

In accordance with Chapter I, install and connect the system (Please read safety considerations carefully), switch on the power supply, self-test of the machine completes after a short time, at this time, the control panel's display is on, remote control's indicator is on, the machine enters into the standby mode.



Note: 1. Please check the reliability of equipment grounding!

2. Whether the water tank's inlet and outlet pipe are connected, otherwise it will result in damage of water tank!

3. Whether the feedback line and grounding line are connected in a reliable way, otherwise it will lead to failure of arc-length automatic control system!

8. 2 Adjust the location of welding torch

Use the remote control (if you have purchased an automatic welding head configuration keyboard you can also use the operation keyboard), make precise positioning of tungsten electrode before welding!



Forward control of welding torch rotating



Reverse control of welding torch rotating



Enhancing control of tungsten crucibleneedle



Dropping control of tungsten crucibleneedle



Inward swing of tungsten crucibleneedle



Outward swing of tungsten crucibleneedle

It is used for precise positioning of height and swing position of tungsten crucibleneedle (carefully uses this function, please note the effective route of arc length slide in using)



Note: Read the instruction carefully before using welding torch!

8. 3 Setting of wire feed location

Use the two buttons on the remote control



It is used to control the welding wire to stretch forward



It is used to control the welding wire to withdraw

This function allows fast and precise positioning of welding wire, release the button to stop the welding wire.



Note: choose the right wire, the extended length of the welding wire must conform to standards and please carefully read the wire feeder instruction for details!

8. 4 Program selection

Through the display screen, check whether the number of program displays on the

screen  

is required, in order to change the program number, you can use the

button  or 

of the remote control to select the appropriate program.



Note: Please check carefully whether the program number is required, the wrong program may lead to lower quality welding or burning-out of tungsten electrode and workpiece!

8. 5 System test and simulation welding

In order to check whether the program welding works properly, the system can be tested firstly, detect whether the following parameters are normal:

I Detect water, gas by remote control



Test whether protective gas is normal



Test whether the cooling water is normal



Note: Prohibit welding when the cooling water, shielding gas are not normal, it may damage equipment or lead to other dangers!

II Simulation of welding

In order to check whether a program is appropriate to a welded part, and whether the positioning is accurate, simulation welding can be taken firstly, it can simulate the process of welding in the absence of current, the gas can be adjusted as moderate in simulation welding.

The choice of simulation can be achieved through  on the control panel ----- non-arc test .

| Program number 05 | | | Simulate | | |
|---------------------------|--------|--------|--------------------------------|-----|--------|
| Diameter of tube | DIA | 38 | Header code | RN | S112 |
| Current mode | K21 | Pulsed | Welding Rotation mode | K31 | Pulsed |
| Wire feed or not | K41 | No | Wire feeder code | SN | 97 |
| AVC control | K51 | Yes | AVC Module code | HN | 21 |
| OSC or not | K61 | Yes | OSC Module code | WN | 21 |
| The number of sub-sector | B | 2 | Welding Rotation degree | N20 | 360 |
| Main gas pre- shield time | T10 | 3 | Main gas lag-shield time | T11 | 3.2 |
| Pre-melting current | I20 | 32 | Pre-melting time | T20 | 1.0 |
| Up-slope time | T21 | 0.1 | Initial Tungsten height or not | K55 | Yes |
| Down-slope time | T25 | 4.2 | Arc shut current | I25 | 13 |
| F4 operation tips | 13: 10 | | A-hand | | |

III Restore setting

After the test, arc / no-arc will be set to no arc

IX Start Welding



After the preparatory work ends, press the button on the remote control, then you can start the welding.

9. 1 Change and adjustment of parameter in welding

In the process of welding, parameters can be modified by remote control, the following parameters in various intervals can be modified:

- Welding current
- Peak base time
- Rotation speed
- Wire feed speed
- Decaying current
- Arc voltage

- Because the metal components of pipeline are different, which makes that operation of these different pipelines adopts more appropriate amendment of parameter, provide the freedom of modification of the original program.
- In each welding cycle, the parameters modified through the remote control only affect parameters in this welding cycle, after welding cycle ends, the parameter is restored to the original setting!
- In the implementation of program of wire feed welding, switch off the wire feed, it will be stopped!



Speed up wire feed



Reduce wire feed speed



Current increases



Current decrease

9. 2 Manual shutdown

At any time in the welding, you may interrupt the welding at any time.

➤ **Press the stop button**


Press the emergency stop on the remote control. You can make the system stop welding (no decay), start the lagging air feed time in order to protect the welding torch and workpiece, while the system will automatically store the current state of welding.

☞ **Note:** The frequent use of this feature may lead to damage to equipments and parts, and

only in an emergency or system crash, it is recommended!

➤ **Manual attenuation**




Press the attenuation button  on the remote control, at this time stop the machine in the following order:

1. Current reduces according to program (attenuation).
2. When the arc is extinguished, the rotation stops, the nose returns to arcing point.
3. After the arc is extinguished, the lagging air feed stops as the setting time in order to protect the welding torch and tungsten electrode.

➤ **Emergency reset**



Press  on the remote control, reset the welding, in the event of an emergency situation or software system failure, use this key.

9. 3 Restart

After stopping the device by the stop button in the event of an emergency, re-start a full welding cycle.

X Common Faults and Detection

In the process of welding, an automatic diagnostic system of the system will automatically monitor the equipment, in the event of a failure, automatic shut-down or attenuation will be made according to different circumstances:

| Phenomenon | Possible Errors | Adjustment |
|-----------------------------------|---|--|
| Master fault | CPU mainboard problem | Bad contact of display panel and CPU mainboard CPU mainboard is damaged, inspection and repair by professionals |
| Display is not normal | Buttons do not respond Macroblocking Blank screen | Restart after 3 minutes since shutdown Display panel failure, inspection and repair by professionals Restart after 3 minutes since shutdown Display power failure Display fault Multimeter measuring input voltage of 0V-5V-12V or not. |
| Overheating | Master control system overheat protection | Restart after 5 minutes of cooling since shutdown |
| Abnormal arcing | Tungsten folder, tungsten electrode, shunt too dirty Tungsten electrode is too far away from the workpiece Master fault | Replacement Adjust the distance Repair by professionals |
| Arc breaking after arcing | Program's unreasonable setting Short of water, the water level is too low | Adjustment of program Water adding |
| Motor is not functioning properly | Drive or motherboard failure Fault of line | Replacement of drive or motherboard Check wiring |
| Water tank leakage | Host cooling pipes are not connected to the water tanks Overpressure rupture of pipe Other factors leading to pipe or container rupture | Replacement of pipes or containers |

| | | |
|-------------------------------------|--|---|
| Operation keyboard does not respond | Accidental operation causes crash Communications system failure | Restart after shutdown Professional inspection and repair |
| Feedback of arc length failure | Failure of feedback part of the motherboard Failure of external feedback line | Check inductance under the feedback socket Check 14 feet of 17-core pin; and 1 foot of 3-core pin; connection to the feedback circuit of motherboard Inductance breakdown |

XI Program Memory

When editing the program, all the information entered is stored in the power supply, once power cut or failure, the memory contents will automatically be protected, but if there is a sudden power failure when the programming is written, it may result in loss of some data, in order to reduce the the risk of such accidents, special emphasis is put on prevention of sudden power failure during programming!

XII Maintenance

In the case of normal using, the welder can be free to use, only minimal maintenance is needed, however, with the purpose of ensuring that the welder cannot go wrong, attention must be paid to some matters, including regular cleaning and inspection, of course, as described below, it is also determined by pollutants in the environment and the using time of welder.

Welder's cleaning, inspection and maintenance must be carried out by professionals. If you do not follow the following requirements, and failure is caused, then do not operate the welder before error correction.

Cleaning

Before cleaning, make sure that the welding machine is separated from the power grid. Please disconnect the power plug. (Cutting off or removal of the fuse does not ensure complete insulation)

Wait for 2 minutes until the power supply is fully discharged, take away things on the power supply.

Separate part should be operated based on the following steps:

- If there is more dust, then use the compressed air to clean the power supply.
- The electronic part of the electrodes, circuit board should be cleaned with a vacuum cleaner

Maintenance

■ Water cooling system (if equipped with water tanks)

Frequently check the cooling device of the water tank of power supply in order to ensure volume of not less than 3 / 4 of volume of water tank. It is proposed to replace coolant every two, the coolant is generally replaced with distilled water, de-ionized pure water is a option if condition is allowed, In the cold area in winter, the coolant should be added with a certain amount of alcohol (concentration 75%).

■ Fuse protection device

In order to protect the safety of equipment and operators, PC508 welding power supply has several fuse protection devices mainly divided into the following parts:

Main loop

Control loop

Power supply of the main printed circuit board

Short-circuit protection

In the process of welding, due to an improper setting or some other reasons, tungsten electrode adheres to the workpiece, then you must immediately stop the welding torch and stop welding in order to protect the welding torch and power supply, if tungsten electrode adheres to the workpiece,seperate the tungsten electrode from the workpiece carefully, then observe whether the tungsten electrode is damaged, if any damage, replace it before using.

\

Repair

The maintenance must be carried out by professionals.

All system failures are generally resolved by equipment suppliers.

If failure is found in the delivery of equipment, the only way to return it is achieved by the dealers.

In the replacement of the parts, you must write clearly the welder model, product serial number and the amount required, you'd better describe the parts clearly.

If the equipment's repair and maintenance are carried out by non-professionals, they should act in accordance with the above considerations.